

Double Filer

Removing a double filer drawer

1. Before removing the drawer from the double filer. Empty the drawer from all contents.
2. Start on the either the left or right side of the drawer. Lift the front of the drawer off the front 2 Clips Fig 1.1
3. To remove the drawer from the slide, hold the drawer and pull the slide forward until the drawer side can be lifted away from the rear clip on the slide. Fig 1.2. Do the same to the other side of the drawer and remove the drawer.
4. To replace the drawer in the double filer unit repeat steps 3 to 1.




Fig 1.1 Lift Drawer of front Clips




Fig 1.2 Removing the drawer